



SIDEM

INSTALLATION INSTRUCTIONS

! Avoid early wear by following the right placement procedure !

Axial joints

- 1 Make sure the steering gaiter isn't damaged and mounted correctly on the steering rack so that no water or dust can infiltrate.



- 2 Tighten all parts according to the constructors instructions.



- 3 After replacing steering parts, a wheel alignment must be executed.

