



Installation Instructions



! Avoid early wear by following the right placement procedure !

Track control arms

- 1 Always tighten the bolts and nuts that connect the ball-joint to the track control arm according to the constructors instructions.
- 2 The bolts and nuts that secure the silentblocks, must always be tightened when the car is placed on its wheels. Otherwise the silentblocks are seriously stretched, and the rubber-metal connection will fail.
- 3 Heat shields must be reinstalled, in case the constructor provided them.
- 4 Make sure that the inner surface is clean and free of rust, before installing a pressed ball-joint.
- 5 Always use the appropriate tool to mount press ball-joints and never use a hammer or another striking tool.

