


## DONNEES TECHNIQUES

Alternator Charge Current [A]	<b>200</b>
Vehicle Main Current	<b>for vehicles with 12V main current</b>
Type de poulie	<b>PVR6F</b>
Clamp	<b>M8 B+</b>
Plug Type ID	<b>PLUG650</b>

## PHOTOS



Bornes	
L	Lamp
DFM	

## DOCUMENTS

**BT-130 Refus des carcasses alternateurs/démarrateurs**

## APPLICATIONS

<b>MERCEDES-BENZ</b>		
SPRINTER 3-t (2006-) (906) Plateau - 311 CDI 4x4 (906.133, 906.135, 906.233, 906.233)	109 ch	06.2006 >
SPRINTER 3-t (2006-) (906) Plateau - 313 CDI	129 ch	06.2006 >
VIANO (W639) - 2.2 CDI	116 ch	08.2005 >
	109 ch	09.2003 >
	150 ch	09.2003 >
VIANO (W639) - 2.2 CDI 4-matic	109 ch	07.2005 >
	150 ch	07.2005 >
VITO (2003-) (W639) Bus - 109 CDI 2.2	88 ch	09.2003 >
	95 ch	09.2006 >
VITO (2003-) (W639) Bus - 109 CDI 2.2 4x4	95 ch	09.2007 >
VITO (2003-) (W639) Bus - 111 CDI 2.2	109 ch	09.2003 >
	116 ch	09.2007 >
VITO (2003-) (W639) Bus - 111 CDI 2.2 4x4	109 ch	09.2007 >
VITO (2003-) (W639) Bus - 115 CDI 2.2	150 ch	09.2003 >
VITO (2003-) (W639) Bus - 115 CDI 2.2 4x4	150 ch	09.2007 >
VITO (2003-) (W639) Camionnette - 109 CDI	95 ch	08.2006 >
VITO (2003-) (W639) Camionnette - 109 CDI 2.2	88 ch	09.2003 >
VITO (2003-) (W639) Camionnette - 111 CDI 2.2	109 ch	09.2003 >
	116 ch	09.2007 >
VITO (2003-) (W639) Camionnette - 111 CDI 2.2 4x4	109 ch	09.2007 >
VITO (2003-) (W639) Camionnette - 115 CDI 2.2	150 ch	09.2003 >
VITO (2003-) (W639) Camionnette - 115 CDI 2.2 4x4	150 ch	09.2007 >