

## DONNEES TECHNIQUES

Length [mm]	<b>700</b>
Number of splines (wheels side)	<b>22</b>
	<b>for vehicles without ABS</b>
(wheels side) shoulder Ø [mm]	<b>56</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>22</b>
(gearbox side) CV Joint Ø [mm]	<b>89</b>
(gearbox side) shoulder Ø [mm]	<b>72</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>LADA</b>		
NIVA (2121) - 1600	73 ch	01.1987 > 03.1995
	76 ch	04.1980 > 12.1987
	76 ch	12.1976 > 05.1987
NIVA (2121) - 1700 i	80 ch	06.1996 >
NIVA (2121) - 1700 i 4x4	82 ch	10.2000 >
NIVA (2121) - 1900 Diesel	64 ch	01.1993 >
	75 ch	01.1999 >
NIVA II (2123) - 1.7	80 ch	09.2002 >

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.