

## DONNEES TECHNIQUES

Compressed length [mm]	<b>612</b>
Uncompressed length [mm]	<b>655</b>
Number of splines (wheels side)	<b>26</b>
Number of Teeth, ABS ring	<b>47</b>
<b>for vehicles with ABS</b>	
(wheels side) shoulder Ø [mm]	<b>54</b>
Position the retaining clip	<b>Gearbox side</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>25</b>
(gearbox side) CV Joint Ø [mm]	<b>89</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

### CHRYSLER

VOYAGER (90-95) (AS, ES) - 2.5 i	98 ch	08.1984 > 09.1995
	101 ch	08.1990 > 09.1995
VOYAGER (90-95) (AS, ES) - 2.5 TD	118 ch	01.1992 > 09.1995

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.