

DONNEES TECHNIQUES

Compressed length [mm]	1002
Number of splines (wheels side)	26
Number of Teeth, ABS ring	47
for vehicles with ABS	
ABS Ring Ø [mm]	96
(wheels side) shoulder Ø [mm]	54
ABS ring type	R
(wheels side) CV Joint Ø [mm]	89
Number of splines (gearbox side)	25
(gearbox side) CV Joint Ø [mm]	89
(gearbox side) shoulder Ø [mm]	30

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

CHRYSLER		
VOYAGER (90-95) (AS, ES) - 3.0 i	147 ch	08.1984 > 09.1995
VOYAGER (90-95) (AS, ES) - 3.3 i	150 ch	08.1990 > 09.1995
	163 ch	08.1990 > 09.1995

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.