

## DONNEES TECHNIQUES

Length [mm]	<b>500</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles without ABS</b>
(wheels side) shoulder Ø [mm]	<b>59</b>
(wheels side) CV Joint Ø [mm]	<b>98</b>
(gearbox side) CV Joint Ø [mm]	<b>108</b>
Number of mounting bores	<b>6</b>
Ø mounting holes [mm]	<b>10</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>ALFA ROMEO</b>		
155 (167) - 2.5 TD (167.A1A)	125 ch	04.1993 > 12.1997

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.