

DONNEES TECHNIQUES

Length [mm]	811
Number of splines (wheels side)	21
Number of Teeth, ABS ring	48
	for vehicles with ABS
ABS ring type	R
(wheels side) CV Joint Ø [mm]	86
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	72

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

CITROËN		
SAXO (S0, S1) - 1.6 VTL,VTR	88 ch	05.1999 > 06.2003
SAXO (S0, S1) - 1.6 VTS	98 ch	09.2000 > 09.2003
	118 ch	05.1999 > 09.2003

PEUGEOT		
106 (96-04) (1_) - 1.4 i	75 ch	05.1999 >
106 (96-04) (1_) - 1.6 i	89 ch	05.1999 >
	101 ch	05.1999 >
106 (96-04) (1_) - 1.6 S16	118 ch	05.1999 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.