


DONNEES TECHNIQUES

Length [mm]	830
Number of splines (wheels side)	21
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	49
(wheels side) CV Joint Ø [mm]	76
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	60
(gearbox side) shoulder Ø [mm]	40

PHOTOS




DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

CITROËN		
AX (ZA-_) - 1.3 Sport	95 ch	04.1987 > 12.1988
AX (ZA-_) - 10	44 ch	09.1986 > 06.1992
	45 ch	07.1986 > 12.1998
	50 ch	02.1987 > 12.1998
AX (ZA-_) - 10 E	41 ch	12.1986 > 12.1988
AX (ZA-_) - 11	54 ch	12.1986 > 04.1994
	60 ch	09.1986 > 12.1997
AX (ZA-_) - 11 4x4	54 ch	06.1991 > 07.1992
AX (ZA-_) - 11 KAT	54 ch	09.1988 > 12.1989
AX (ZA-_) - 14	60 ch	12.1986 > 12.1988
	67 ch	06.1988 > 06.1991
	75 ch	04.1987 > 06.1991
	85 ch	01.1988 > 06.1991
AX (ZA-_) - 14 D	50 ch	08.1991 > 12.1997
	52 ch	09.1988 > 06.1992
SAXO (S0, S1) - 1.0 X	45 ch	05.1996 > 04.1999

CITROËN		
(suite) SAXO (S0, S1) - 1.0 X	50 ch	05.1998 > 04.1999
SAXO (S0, S1) - 1.1 X,SX	54 ch	05.1996 > 04.1999
	60 ch	05.1996 > 04.1999
PEUGEOT		
106 (91-96) (1A, 1C) - 1.0	45 ch	09.1991 > 04.1996
	50 ch	09.1991 > 04.1996
106 (91-96) (1A, 1C) - 1.1	60 ch	09.1991 > 04.1996
106 (96-04) (1_) - 1.0 i	45 ch	05.1996 > 04.1999
	50 ch	01.1997 > 04.1999
106 (96-04) (1_) - 1.1 i	54 ch	01.1997 > 04.1999
	60 ch	05.1996 > 04.1999

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.