

DONNEES TECHNIQUES

Length [mm]	838
Number of splines (wheels side)	21
Number of Teeth, ABS ring	48
	for vehicles with ABS
ABS Ring Ø [mm]	86
(wheels side) shoulder Ø [mm]	49
ABS ring type	R
(wheels side) CV Joint Ø [mm]	76
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	72
(gearbox side) shoulder Ø [mm]	40

PHOTOS



DOCUMENTS


BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS
CITROËN

SAXO (S0, S1) - 1.0 X	50 ch	05.1999 > 06.2003
SAXO (S0, S1) - 1.1 X,SX	54 ch	05.1999 > 09.2003
	60 ch	05.1999 > 09.2003
SAXO (S0, S1) - 1.4 VTS	75 ch	05.1999 > 06.2003
SAXO (S0, S1) - 1.5 D	54 ch	05.1999 > 09.2003
	57 ch	05.1999 > 06.2001

PEUGEOT

106 (96-04) (1_) - 1.0 i	45 ch	05.1999 >
	50 ch	05.1999 >
106 (96-04) (1_) - 1.1 i	54 ch	05.1999 >
	60 ch	05.1999 >
106 (96-04) (1_) - 1.4 i	75 ch	05.1999 >
106 (96-04) (1_) - 1.5 D	55 ch	05.1999 >
	57 ch	10.2000 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.