

## DONNEES TECHNIQUES

Compressed length [mm]	<b>595</b>
Uncompressed length [mm]	<b>625</b>
Number of splines (wheels side)	<b>25</b>
Number of Teeth, ABS ring	<b>29</b>
<b>for vehicles with ABS</b>	
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>86</b>
Number of splines (gearbox side)	<b>22</b>
(gearbox side) CV Joint Ø [mm]	<b>72</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>CITROËN</b>		
XSARA (N1) - 1.4 i	75 ch	04.1997 > 08.2000
XSARA (N1) - 1.5 D	57 ch	04.1997 > 09.2000
XSARA (N1) - 1.6 i	88 ch	04.1997 > 03.1998
XSARA Break (N2) - 1.4 i	75 ch	10.1997 > 08.2000
XSARA Break (N2) - 1.5 D	57 ch	10.1997 > 09.2000
XSARA Break (N2) - 1.6 i	88 ch	10.1997 > 09.2000
XSARA Coupe (N0) - 1.4 i	75 ch	03.1998 > 08.2000
XSARA Coupe (N0) - 1.6 i	88 ch	02.1998 > 09.2000

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.