

DONNEES TECHNIQUES

Length [mm]	1065
Number of splines (wheels side)	28
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	63
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	25
(gearbox side) CV Joint Ø [mm]	100
(gearbox side) shoulder Ø [mm]	28

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

CITROËN		
C25 (280_, 290_) Bus - 1.9 D	69 ch	07.1987 > 02.1994
C25 (280_, 290_) Bus - 1.9 TD	82 ch	04.1992 > 02.1994

FIAT		
DUCATO (81-90) Camionnette (280) - 1.9 D	71 ch	01.1988 > 08.1990
DUCATO (81-90) Camionnette (280) - 1.9 TD	82 ch	03.1989 > 08.1990
DUCATO (81-90) Panorama (280) - 1.9 D	71 ch	02.1987 > 08.1990
DUCATO (81-90) Panorama (280) - 1.9 TD	82 ch	03.1989 > 08.1990
DUCATO (81-90) Plateau (280) - 1.9 D	71 ch	01.1988 > 08.1990
DUCATO (81-90) Plateau (280) - 1.9 TD	82 ch	03.1989 > 08.1990
DUCATO (90-94) Camionnette (290) - 1.9 D	71 ch	07.1990 > 03.1994
DUCATO (90-94) Camionnette (290) - 1.9 TD	82 ch	03.1989 > 03.1994
DUCATO (90-94) Panorama (290) - 1.9 D	71 ch	07.1990 > 03.1994
DUCATO (90-94) Panorama (290) - 1.9 TD	82 ch	07.1990 > 03.1994
DUCATO (90-94) Plateau (290) - 1.9 TD	82 ch	03.1989 > 03.1994

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.