


DONNEES TECHNIQUES

Compressed length [mm]	865
Number of splines (wheels side)	25
for vehicles without ABS	
(wheels side) CV Joint Ø [mm]	79
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	76

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions


APPLICATIONS

CITROËN

BERLINGO (96-10) (MF) - 1.1 i (MFHDZ)	60 ch	07.1996 >
BERLINGO (96-10) (MF) - 1.4 bivalent	65 ch	11.2002 >
BERLINGO (96-10) (MF) - 1.4 i (MFKFX)	75 ch	07.1996 >
BERLINGO (96-10) (MF) - 1.4 i bivalent	75 ch	04.2003 >
BERLINGO (96-10) Camionnette (M_) - 1.1 i (MAHDZ, MBHDZ)	60 ch	07.1996 >
BERLINGO (96-10) Camionnette (M_) - 1.4 bivalent	65 ch	11.2002 >
BERLINGO (96-10) Camionnette (M_) - 1.4 i (MBKFX)	75 ch	07.1996 >
BERLINGO (96-10) Camionnette (M_) - 1.4 i bivalent	75 ch	04.2003 >

PEUGEOT

PARTNER (97-07) Camionnette (5) - 1.1	60 ch	06.1996 >
PARTNER (97-07) Camionnette (5) - 1.4	75 ch	06.1996 >
PARTNER (97-07) Camionnette (5) - 1.4 BiFuel	75 ch	04.2003 >
PARTNER (97-07) Combispace (5F) - 1.1	60 ch	06.1996 >
PARTNER (97-07) Combispace (5F) - 1.4	75 ch	06.1996 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.