

DONNEES TECHNIQUES

Compressed length [mm]	865
Uncompressed length [mm]	895
Number of splines (wheels side)	25
for vehicles without ABS	
(wheels side) shoulder Ø [mm]	55
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	24
(gearbox side) CV Joint Ø [mm]	81

PHOTOS



DOCUMENTS

- | | |
|---------------|--|
| BT-100 | Conseils de montage des cardans |
| BT-104 | Soufflets et Triaxes FIAT |
| BT-105 | Soufflets et Triaxes SEAT |
| BT-131 | Refus des carcasses transmissions |


APPLICATIONS

CITROËN

BERLINGO (96-10) (MF) - 1.6 16V (MFNFU)	109 ch	10.2000 >
BERLINGO (96-10) (MF) - 1.8 D (MFA9A)	58 ch	07.1998 >
BERLINGO (96-10) (MF) - 1.8 i (MFLFX)	90 ch	05.1997 >
BERLINGO (96-10) (MF) - 1.8 i 4WD (MFLFX)	90 ch	04.1997 >
BERLINGO (96-10) (MF) - 1.9 D (MFDJY)	68 ch	07.1996 >
BERLINGO (96-10) (MF) - 1.9 D (MFWJZ)	70 ch	07.1998 >
BERLINGO (96-10) (MF) - 1.9 D 4WD (MFWJZ)	69 ch	07.1998 >
BERLINGO (96-10) (MF) - 2.0 HDI 90 (MFRHY)	90 ch	12.1999 >
BERLINGO (96-10) Camionnette (M_) - 1.6 16V	109 ch	10.2000 >
BERLINGO (96-10) Camionnette (M_) - 1.8 D (MBA9A, MCA9A)	59 ch	07.1996 >
BERLINGO (96-10) Camionnette (M_) - 1.8 i	90 ch	08.1999 > 10.2002
BERLINGO (96-10) Camionnette (M_) - 1.9 D	70 ch	07.1996 >
BERLINGO (96-10) Camionnette (M_) - 1.9 D 70 4WD	69 ch	07.1998 >
BERLINGO (96-10) Camionnette (M_) - 1.9 D 70 (MBWJZ, MCWJZ)	69 ch	04.1999 >

PEUGEOT

PARTNER (97-07) Camionnette (5) - 1.8 D	58 ch	06.1996 >
PARTNER (97-07) Camionnette (5) - 1.9 D	69 ch	06.1996 >
	69 ch	06.1996 >
PARTNER (97-07) Combispace (5F) - 1.6 16V	109 ch	07.2001 >
PARTNER (97-07) Combispace (5F) - 1.8	90 ch	05.1997 >
PARTNER (97-07) Combispace (5F) - 1.9 D	68 ch	06.1996 >
	69 ch	12.1998 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.