

DONNEES TECHNIQUES

Compressed length [mm]	953
Uncompressed length [mm]	985
Number of splines (wheels side)	27
Number of Teeth, ABS ring	48
for vehicles with ABS	
ABS Ring Ø [mm]	99
(wheels side) shoulder Ø [mm]	61
ABS ring type	R
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	37
(gearbox side) CV Joint Ø [mm]	89

PHOTOS



DOCUMENTS

- | | |
|---------------|--|
| BT-100 | Conseils de montage des cardans |
| BT-104 | Soufflets et Triaxes FIAT |
| BT-105 | Soufflets et Triaxes SEAT |
| BT-131 | Refus des carcasses transmissions |

APPLICATIONS
CITROËN

EVASION (22, U6) - 2.0 HDI	109 ch	08.1999 > 07.2002
JUMPY (95-07) (U6U) - 2.0 HDi 95	94 ch	10.1999 >
JUMPY (95-07) (U6U) - 2.0 HDi 110	109 ch	03.2000 >
JUMPY (95-07) Camionnette (BS/T/Y/Z_) - 2.0 HDi 95	94 ch	10.1999 >
JUMPY (95-07) Camionnette (BS/T/Y/Z_) - 2.0 HDi 110	109 ch	01.2002 >
JUMPY (95-07) Plateau (BU/V/W/X_) - 2.0 HDi 95	94 ch	10.1999 >

FIAT


SCUDO (95-07) Camionnette (220L) - 2.0 JTD	94 ch	12.1999 >
	109 ch	12.2002 >
SCUDO (95-07) Combinato (220P) - 2.0 JTD	94 ch	01.2004 >
	109 ch	12.1999 >
ULYSSE (220) - 2.0 JTD	109 ch	10.1999 > 08.2002

LANCIA

ZETA (220) - 2.0 JTD (220AN5)	109 ch	09.1999 > 09.2002
-------------------------------	--------	-------------------

PEUGEOT

806 (221) - 2.0 HDI	109 ch	08.1999 > 08.2002
806 (221) - 2.0 HDI 16V	109 ch	08.1999 > 08.2002
EXPERT (95-07) (224) - 2.0 HDI	109 ch	07.2000 >
	109 ch	07.2000 >
EXPERT (95-07) Camionnette (222) - 2.0 HDI	94 ch	07.2000 >
	109 ch	07.2000 >
	109 ch	07.2000 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.