

DONNEES TECHNIQUES

Compressed length [mm]	640
Uncompressed length [mm]	680
Number of splines (wheels side)	27
Number of Teeth, ABS ring	48
for vehicles with ABS	
ABS Ring Ø [mm]	99
(wheels side) shoulder Ø [mm]	61
ABS ring type	R
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	37
(gearbox side) CV Joint Ø [mm]	89

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS
CITROËN

EVASION (22, U6) - 1.9 TD	90 ch	11.1994 > 07.2002
	92 ch	10.1995 > 12.1998
EVASION (22, U6) - 2.0 TD	92 ch	05.1997 > 07.2002
EVASION (22, U6) - 2.0 Turbo C.T.	147 ch	06.1994 > 07.2002
EVASION (22, U6) - 2.1 TD	109 ch	05.1996 > 07.2002
JUMPY (95-07) (U6U) - 1.9 TD	90 ch	10.1995 >
	92 ch	04.1996 >
JUMPY (95-07) (U6U) - 2.0	136 ch	04.2000 > 12.2006
JUMPY (95-07) (U6U) - 2.0 i 16V	138 ch	03.2000 >
JUMPY (95-07) Camionnette (BS/T/Y/Z_) - 1.9 TD	90 ch	10.1995 >
JUMPY (95-07) Camionnette (BS/T/Y/Z_) - 2.0 i 16V	138 ch	03.2000 >
JUMPY (95-07) Plateau (BU/V/W/X_) - 1.9 TD	92 ch	10.1999 >
JUMPY (2007-) (XA_, XC_) - 2.0 i	140 ch	01.2007 >
JUMPY (2007-) Camionnette (XA_, XC_) - 2.0 i	140 ch	01.2007 >

FIAT


SCUDO (95-07) Camionnette (220L) - 1.9 TD	90 ch	02.1996 >
	92 ch	02.1998 >
SCUDO (95-07) Combinato (220P) - 1.9 TD	92 ch	02.1996 >
SCUDO (95-07) Combinato (220P) - 1.9 TD Eco	90 ch	02.1996 >
ULYSSE (220) - 1.9 TD (220AH5)	90 ch	02.1995 > 08.2002
ULYSSE (220) - 2.0 Turbo (220.AD5)	147 ch	06.1994 > 08.2002
ULYSSE (220) - 2.1 TD	109 ch	03.1996 > 10.1999

LANCIA

ZETA (220) - 2.0 Turbo (220AD5, 220CD5)	147 ch	05.1995 > 09.2002
ZETA (220) - 2.1 TD (220AJ5)	109 ch	05.1996 > 09.1999

PEUGEOT

806 (221) - 1.9 TD	90 ch	07.1995 > 08.2002
	92 ch	05.1997 > 08.2002
806 (221) - 2.0 Turbo	147 ch	06.1994 > 08.2002
806 (221) - 2.1 td 12V	109 ch	06.1996 > 08.1999
EXPERT (95-07) (224) - 1.9 TD	90 ch	02.1996 >
	92 ch	02.1996 >
EXPERT (95-07) (224) - 2.0	136 ch	07.2000 >
EXPERT (95-07) Camionnette (222) - 1.9 TD	90 ch	02.1996 >
	92 ch	02.1996 >
EXPERT (95-07) Camionnette (222) - 2.0	136 ch	09.2002 >
EXPERT (95-07) plateau (223) - 1.9 TD	90 ch	02.1996 >
	92 ch	02.1996 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.