

## DONNEES TECHNIQUES

Length [mm]	<b>611</b>
Number of splines (wheels side)	<b>33</b>
Number of Teeth, ABS ring	<b>45</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>81</b>
Thread (wheels side)	<b>FEMELLE</b>
(wheels side) shoulder Ø [mm]	<b>53</b>
ABS ring type	<b>W</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
(gearbox side) CV Joint Ø [mm]	<b>108</b>
Number of mounting bores	<b>6</b>
Ø mounting holes [mm]	<b>10</b>

## PHOTOS




## DOCUMENTS

- BT-100**    **Conseils de montage des cardans**
- BT-104**    **Soufflets et Triaxes FIAT**
- BT-105**    **Soufflets et Triaxes SEAT**
- BT-131**    **Refus des carcasses transmissions**

## APPLICATIONS

<b>AUDI</b>		
A4 (94-01) (8D2, B5) - 1.8	115 ch	04.1995 > 11.2000
	125 ch	01.1995 > 11.2000
A4 (94-01) (8D2, B5) - 1.8 T	150 ch	01.1995 > 11.2000
A4 (94-01) Avant (8D5, B5) - 1.8	115 ch	07.1995 > 09.2001
	125 ch	02.1996 > 09.2001
A4 (94-01) Avant (8D5, B5) - 1.8 T	150 ch	03.1996 > 09.2001

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.