

DONNEES TECHNIQUES

Length [mm]	645
Number of splines (wheels side)	26
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	49
(wheels side) CV Joint Ø [mm]	80
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	78

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

ROVER		
200 Hatchback (XW) - 214	75 ch	09.1993 > 10.1995
200 Hatchback (XW) - 214 GSi/Si	95 ch	01.1990 > 10.1995
	103 ch	12.1992 > 10.1995
200 Hatchback (XW) - 214 Si/Gsi	90 ch	10.1989 > 10.1995
400 (XW) - 414	95 ch	01.1993 > 04.1995
400 (XW) - 414 GSI/SI	90 ch	04.1990 > 04.1995
400 (XW) - 414 GSI/SI KAT	103 ch	01.1993 > 04.1995
CABRIOLET (XW) - 214 1.4	90 ch	01.1992 > 11.1999
	95 ch	04.1990 > 09.1992
CABRIOLET (XW) - 214 1.4i 16V	103 ch	01.1993 > 11.1999

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.