

## DONNEES TECHNIQUES

Length [mm]	<b>610</b>
Number of splines (wheels side)	<b>26</b>
Number of Teeth, ABS ring	<b>50</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>49</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>83</b>
Number of splines (gearbox side)	<b>27</b>
(gearbox side) CV Joint Ø [mm]	<b>85</b>
	<b>Coupling (gearbox side) not supplied</b>
	<b>Supplied without bearing (gearbox side)</b>

## PHOTOS

## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>ROVER</b>		
200 Coupe (XW) - 216	122 ch	10.1992 > 06.1999
200 Hatchback (XW) - 216 GSi	112 ch	10.1989 > 10.1995
	116 ch	10.1989 > 10.1995
200 Hatchback (XW) - 216 GTi	122 ch	09.1990 > 10.1995
	130 ch	09.1990 > 10.1995

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.