

## DONNEES TECHNIQUES

Length [mm]	<b>588</b>
Number of splines (wheels side)	<b>26</b>
Number of Teeth, ABS ring	<b>43</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>49</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>29</b>
(gearbox side) CV Joint Ø [mm]	<b>90</b>

## PHOTOS



## DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

## APPLICATIONS

<b>ROVER</b>		
25 (RF) - 2.0 iDT	101 ch	10.1999 >
200 (RF) - 220 D/SD	86 ch	11.1995 > 03.2000
200 (RF) - 220 SDi	105 ch	11.1995 > 03.2000
200 Coupe (XW) - 220 GSi	136 ch	05.1994 > 06.1999
200 Coupe (XW) - 220 Turbo	200 ch	10.1992 > 06.1999
200 Hatchback (XW) - 220 GTi	136 ch	01.1993 > 10.1995
	140 ch	09.1991 > 10.1995
200 Hatchback (XW) - 220 Turbo	200 ch	01.1993 > 10.1995
400 (RT) - 420 Si Lux	136 ch	12.1995 > 03.2000
400 (XW) - 420 GSI/SLI/GTI/Vite	136 ch	01.1993 > 04.1995
400 (XW) - 420 GTI/GSI/Vitesse	140 ch	02.1992 > 04.1995
400 (XW) - 420 Turbo	200 ch	01.1993 > 04.1995
400 Hatchback (RT) - 420 Si Lux	136 ch	12.1995 > 03.2000
400 Tourer (XW) - 2.0 i	136 ch	05.1994 > 11.1998