

## DONNEES TECHNIQUES

Length [mm]	<b>965</b>
Number of splines (wheels side)	<b>26</b>
Number of Teeth, ABS ring	<b>43</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>55</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>88</b>
Number of splines (gearbox side)	<b>29</b>
(gearbox side) CV Joint Ø [mm]	<b>86</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>HONDA</b>		
CIVIC (95-01) Aerodeck (MB, MC) - 2.0 i D (MC3)	105 ch	04.1998 > 02.2001
CIVIC (95-01) Fastback (MA, MB) - 2.0 i TD (MB7)	86 ch	01.1997 > 02.2001
CIVIC (95-01) Fastback (MA, MB) - 2.0 TDiC	105 ch	11.1998 > 10.2000
CIVIC (95-01) Hatchback (EJ9, EK1/3/4) - 2.0 TDiC	105 ch	11.1998 > 10.2000

<b>ROVER</b>		
45 (RT) - 2.0 iDT	101 ch	02.2000 >
400 (RT) - 420 D	86 ch	11.1995 > 03.2000
400 (RT) - 420 Di	105 ch	05.1995 > 03.2000
400 Hatchback (RT) - 420 D	86 ch	11.1995 > 03.2000
400 Hatchback (RT) - 420 Di	105 ch	05.1995 > 03.2000

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.