

DONNEES TECHNIQUES

| | |
|----------------------------------|------------|
| Length [mm] | 565 |
| Number of splines (wheels side) | 26 |
| Number of Teeth, ABS ring | 43 |
| for vehicles with ABS | |
| (wheels side) shoulder Ø [mm] | 55 |
| ABS ring type | R |
| (wheels side) CV Joint Ø [mm] | 88 |
| Number of splines (gearbox side) | 29 |
| (gearbox side) CV Joint Ø [mm] | 86 |

PHOTOS




DOCUMENTS

| | |
|---------------|--|
| BT-100 | Conseils de montage des cardans |
| BT-104 | Soufflets et Triaxes FIAT |
| BT-105 | Soufflets et Triaxes SEAT |
| BT-131 | Refus des carcasses transmissions |

APPLICATIONS

| HONDA | | |
|---|--------|-------------------|
| CIVIC (95-01) Aerodeck (MB, MC) - 2.0 i D (MC3) | 105 ch | 04.1998 > 02.2001 |
| CIVIC (95-01) Fastback (MA, MB) - 2.0 i TD (MB7) | 86 ch | 01.1997 > 02.2001 |
| CIVIC (95-01) Fastback (MA, MB) - 2.0 TDiC | 105 ch | 11.1998 > 10.2000 |
| CIVIC (95-01) Hatchback (EJ9, EK1/3/4) - 2.0 TDiC | 105 ch | 11.1998 > 10.2000 |

| ROVER | | |
|-----------------------------|--------|-------------------|
| 45 (RT) - 2.0 iDT | 101 ch | 02.2000 > |
| 400 (RT) - 420 D | 86 ch | 11.1995 > 03.2000 |
| 400 (RT) - 420 Di | 105 ch | 05.1995 > 03.2000 |
| 400 Hatchback (RT) - 420 D | 86 ch | 11.1995 > 03.2000 |
| 400 Hatchback (RT) - 420 Di | 105 ch | 05.1995 > 03.2000 |

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.