

DONNEES TECHNIQUES

Length [mm]	580
Number of splines (wheels side)	22
Number of Teeth, ABS ring	29
	for vehicles with ABS
(wheels side) shoulder Ø [mm]	52
ABS ring type	R
(wheels side) CV Joint Ø [mm]	82
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	85
(gearbox side) shoulder Ø [mm]	35

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

OPEL		
COMBO C Camionnette/Break - 1.7 DI 16V	65 ch	10.2001 >
COMBO C Camionnette/Break - 1.7 DTI 16V	75 ch	10.2001 >
COMBO C Tour - 1.3 CDTI 16V	69 ch	10.2004 >
COMBO C Tour - 1.7 DI 16V	65 ch	10.2001 >
COMBO C Tour - 1.7 DTI 16V	75 ch	10.2001 >
CORSA C (00-06) (F08, F68) - 1.3 CDTI	70 ch	06.2003 >
CORSA C (00-06) (F08, F68) - 1.4	90 ch	09.2000 >
CORSA C (00-06) (F08, F68) - 1.6	97 ch	08.2005 > 07.2006
CORSA C (00-06) (F08, F68) - 1.7 DI	65 ch	09.2000 >
CORSA C (00-06) (F08, F68) - 1.7 DTI	75 ch	09.2000 >
CORSA C (00-06) (F08, F68) - 1.8	125 ch	09.2000 >
CORSA C (00-06) Camionnette (F08, W5L) - 1.3 CDTI 16V	69 ch	08.2005 >
CORSA C (00-06) Camionnette (F08, W5L) - 1.6	97 ch	08.2005 >
CORSA C (00-06) Camionnette (F08, W5L) - 1.7 DI 16V	65 ch	09.2000 >
CORSA C (00-06) Camionnette (F08, W5L) - 1.7 DTI 16V	75 ch	09.2000 >
MERIVA A (03-10) - 1.4 16V Twinport	90 ch	07.2004 > 05.2010
TIGRA TwinTop - 1.3 CDTI	69 ch	06.2004 >
TIGRA TwinTop - 1.4	90 ch	06.2004 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.