

DONNEES TECHNIQUES

Compressed length [mm]	885
Uncompressed length [mm]	930
Number of splines (wheels side)	25
Number of Teeth, ABS ring	29
for vehicles with ABS	
ABS Ring Ø [mm]	90
(wheels side) shoulder Ø [mm]	57
ABS ring type	R or W
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	24
(gearbox side) CV Joint Ø [mm]	81
(gearbox side) shoulder Ø [mm]	30

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions


APPLICATIONS

CITROËN

BERLINGO (96-10) Camionnette (M_) - 2.0 HDI 90 4WD	90 ch	11.2000 >
BERLINGO (96-10) Camionnette (M_) - 2.0 HDI 90 (MBRHY, MCRHY)	90 ch	12.1999 >

PEUGEOT

306 3 volumes (7B, N3, N5) - 1.9 SRDT	90 ch	06.1994 > 05.2001
306 3 volumes (7B, N3, N5) - 2.0	132 ch	03.1997 > 05.2001
306 3 volumes (7B, N3, N5) - 2.0 HDI 90	90 ch	06.1999 > 05.2001
306 3 volumes (7B, N3, N5) - 2.0 S16	150 ch	06.1994 > 05.2001
	152 ch	06.1994 > 05.2001
306 3/5 portes (7A, 7C, N3, N5) - 1.9 DT	90 ch	05.1993 > 05.2001
306 3/5 portes (7A, 7C, N3, N5) - 2.0 HDI 90	90 ch	06.1999 > 05.2001
306 3/5 portes (7A, 7C, N3, N5) - 2.0 S16	150 ch	06.1994 > 05.2001
	152 ch	05.1993 > 05.2001
	163 ch	03.1996 > 05.2001
306 Break (7E, N3, N5) - 1.9 TD	90 ch	02.1997 > 04.2002
306 Break (7E, N3, N5) - 2.0	132 ch	03.1997 > 04.2002
306 Break (7E, N3, N5) - 2.0 HDI 90	90 ch	06.1999 > 04.2002
306 Cabriolet (7D, N3, N5) - 2.0	121 ch	03.1994 > 04.2002
607 (9D, 9U) - 2.0 HDI	109 ch	05.2000 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.