

DONNEES TECHNIQUES

Compressed length [mm]	607
Uncompressed length [mm]	640
Number of splines (wheels side)	21
Number of Teeth, ABS ring	48
for vehicles with ABS	
ABS Ring Ø [mm]	86
ABS ring type	R
(wheels side) CV Joint Ø [mm]	86
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	72

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions


APPLICATIONS

CITROËN

AX (ZA-_) - 1.4 GTi	90 ch	08.1991 > 12.1996
	94 ch	06.1991 > 12.1996
	100 ch	06.1991 > 12.1992
SAXO (S0, S1) - 1.6 VTL,VTR	88 ch	05.1996 > 04.1999
SAXO (S0, S1) - 1.6 VTS	118 ch	06.1996 > 04.1999

PEUGEOT

106 (91-96) (1A, 1C) - 1.3	98 ch	10.1993 > 04.1996
106 (91-96) (1A, 1C) - 1.4	94 ch	07.1993 > 04.1996
106 (91-96) (1A, 1C) - 1.6	103 ch	01.1994 > 04.1996
106 (96-04) (1_) - 1.6 i	89 ch	05.1996 > 04.1999
	101 ch	05.1996 > 04.1999
106 (96-04) (1_) - 1.6 S16	118 ch	05.1996 > 04.1999

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.