

DONNEES TECHNIQUES

Length [mm]	875
Number of splines (wheels side)	25
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	56
(wheels side) CV Joint Ø [mm]	83
Number of splines (gearbox side)	24
(gearbox side) CV Joint Ø [mm]	70
(gearbox side) shoulder Ø [mm]	30

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

PEUGEOT		
405 (87-92) (15B) - 1.6	72 ch	07.1987 > 12.1992
	75 ch	07.1987 > 06.1988
	88 ch	07.1987 > 12.1992
	90 ch	10.1989 > 12.1992
	94 ch	01.1987 > 12.1992
405 (87-92) (15B) - 1.9	95 ch	07.1987 > 12.1992
	109 ch	07.1988 > 12.1992
405 (87-92) (15B) - 1.9 Diesel	64 ch	07.1988 > 09.1992
	69 ch	03.1988 > 12.1992
405 (87-92) Break (15E) - 1.6	72 ch	10.1988 > 08.1992
	75 ch	10.1988 > 08.1992
	88 ch	10.1988 > 08.1992
	90 ch	10.1988 > 08.1992
	94 ch	10.1988 > 08.1992
405 (87-92) Break (15E) - 1.9 D	64 ch	10.1988 > 08.1992
	69 ch	10.1988 > 08.1992

PEUGEOT		
405 (92-96) (4B) - 1.6	88 ch	08.1992 > 10.1995
405 (92-96) (4B) - 1.8	101 ch	08.1992 > 10.1995
405 (92-96) Break (4E) - 1.6	88 ch	08.1992 > 10.1996
405 (92-96) Break (4E) - 1.8	101 ch	08.1992 > 10.1996

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.