

DONNEES TECHNIQUES

Length [mm]	695
Number of splines (wheels side)	30
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	30
(gearbox side) CV Joint Ø [mm]	95

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

PEUGEOT		
J9 Bus - 2.0	78 ch	11.1982 > 06.1987
J9 Bus - 2.5 D	72 ch	11.1982 > 06.1987
J9 Camionnette - 1.6	60 ch	11.1982 > 06.1987
J9 Camionnette - 2.0	78 ch	11.1982 > 06.1987
J9 Camionnette - 2.1 D	56 ch	11.1982 > 06.1987
J9 Camionnette - 2.3 D	67 ch	03.1980 > 07.1982
J9 Camionnette - 2.5 D	72 ch	11.1982 > 06.1987
J9 plateau - 2.0	78 ch	11.1982 > 06.1987
J9 plateau - 2.3 D	67 ch	03.1980 > 07.1982
J9 plateau - 2.5 D	72 ch	11.1982 > 06.1987

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.