

## DONNEES TECHNIQUES

Length [mm]	<b>645</b>
Number of splines (wheels side)	<b>25</b>
Number of Teeth, ABS ring	<b>48</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>100</b>
(wheels side) shoulder Ø [mm]	<b>59</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>24</b>
(gearbox side) CV Joint Ø [mm]	<b>81</b>
(gearbox side) shoulder Ø [mm]	<b>40</b>

## PHOTOS




## DOCUMENTS

- |               |  |
|---------------|--|
| <b>BT-100</b> | <b>Conseils de montage des cardans</b>   |
| <b>BT-104</b> | <b>Soufflets et Triaxes FIAT</b>         |
| <b>BT-105</b> | <b>Soufflets et Triaxes SEAT</b>         |
| <b>BT-131</b> | <b>Refus des carcasses transmissions</b> |

## APPLICATIONS

<b>PEUGEOT</b>		
406 (8B) - 1.6	88 ch	04.1999 > 05.2004
406 (8B) - 1.8	90 ch	04.1999 > 05.2004
406 (8B) - 1.8 16V	110 ch	04.1999 > 10.2000
	116 ch	10.2000 > 05.2004
406 (8B) - 1.9 D	75 ch	04.1999 > 05.2004
406 Break (8E/F) - 1.8	90 ch	04.1999 > 10.2004
406 Break (8E/F) - 1.8 16V	110 ch	10.1996 > 10.2000
	116 ch	10.2000 > 10.2004
406 Break (8E/F) - 1.9 D	75 ch	04.1999 > 10.2004

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.