

## DONNEES TECHNIQUES

Compressed length [mm]	<b>835</b>
Uncompressed length [mm]	<b>843</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles without ABS</b>
(wheels side) shoulder Ø [mm]	<b>56</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>24</b>
(gearbox side) CV Joint Ø [mm]	<b>76</b>
(gearbox side) shoulder Ø [mm]	<b>30</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>PEUGEOT</b>		
205 (83-87) (741A/C) - 1.9 GTI	102 ch	03.1987 > 10.1987
	128 ch	10.1986 > 10.1987
205 (86-94) Cabriolet (741B, 20D) - 1.9 CTI	102 ch	10.1987 > 12.1994
205 (87-98) (20A/C) - 1.9 GTI	102 ch	10.1987 > 05.1989
	120 ch	10.1987 > 10.1994
	128 ch	10.1987 > 09.1998
205 (87-98) (20A/C) - 1.9 GTI KAT	102 ch	10.1987 > 07.1994

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.