

DONNEES TECHNIQUES

Length [mm]	835
Number of splines (wheels side)	21
for vehicles without ABS	
(wheels side) shoulder Ø [mm]	56
(wheels side) CV Joint Ø [mm]	86
Number of splines (gearbox side)	22
(gearbox side) CV Joint Ø [mm]	72
(gearbox side) shoulder Ø [mm]	30

PHOTOS




DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

CITROËN		
C15 (VD-_) - 1.0	45 ch	08.1987 > 12.1997
C15 (VD-_) - 1.1 i	60 ch	07.1988 > 12.1996
C15 (VD-_) - 1.4	67 ch	07.1987 > 12.1996
C15 (VD-_) - 1.4 E	55 ch	07.1987 > 12.1996
	60 ch	08.1987 > 12.1996
C15 (VD-_) - 1.4 i	75 ch	05.1991 > 12.1996

PEUGEOT		
205 (86-94) Cabriolet (741B, 20D) - 1.4 CJ	60 ch	03.1988 > 05.1989
	67 ch	03.1989 > 12.1994
	75 ch	05.1991 > 12.1994
205 (86-94) Cabriolet (741B, 20D) - 1.4 CJ KAT	60 ch	01.1989 > 09.1993
205 (86-94) Cabriolet (741B, 20D) - 1.4 CT	79 ch	04.1986 > 12.1988
205 (87-98) (20A/C) - 1.3 Rallye	101 ch	10.1987 > 10.1990
205 (87-98) (20A/C) - 1.4	60 ch	10.1987 > 05.1989
	67 ch	10.1987 > 10.1990
	72 ch	01.1987 > 07.1988
	75 ch	07.1988 > 09.1998
	75 ch	08.1990 > 07.1998
	79 ch	07.1988 > 05.1989
	84 ch	06.1987 > 12.1989
	86 ch	06.1987 > 12.1989
205 (87-98) (20A/C) - 1.4 KAT	60 ch	08.1987 > 09.1993

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.