

## DONNEES TECHNIQUES

Compressed length [mm]	<b>942</b>
Uncompressed length [mm]	<b>972</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles with ABS</b>
ABS ring type	<b>On hub</b>
(wheels side) CV Joint Ø [mm]	<b>100</b>
Number of splines (gearbox side)	<b>37</b>
(gearbox side) CV Joint Ø [mm]	<b>90</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>CITROËN</b>		
C5 (01-04) (DC_) - 2.0 HDi (DCRHZB, DCRHZE)	109 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.2 HDi (DC4HXB, DC4HXE)	133 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 3.0 V6 (DCXFXC, DCXFXF)	207 ch	03.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 HDi (DERHSB, DERHSE)	107 ch	06.2001 > 08.2004
C5 (01-04) Break (DE_) - 3.0 V6 (DEXFXC, DEXFXF)	207 ch	06.2001 > 08.2004

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.