

DONNEES TECHNIQUES

Compressed length [mm]	940
Uncompressed length [mm]	965
Number of splines (wheels side)	25
	for vehicles with ABS
(wheels side) shoulder Ø [mm]	59
ABS ring type	On hub
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	24
(gearbox side) CV Joint Ø [mm]	90

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

CITROËN		
C4 (2010-) (B7) - 1.6 16V	120 ch	11.2009 >
C4 (2010-) (B7) - 1.6 HDi 90	92 ch	11.2009 >
C5 (01-04) (DC_) - 1.8 16V (DC6FZB, DC6FZE)	115 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.0 16V (DCRFNC, DCRFNF)	136 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.0 16V HPi (DCRLZB)	140 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.0 HDi (DCRHYB)	90 ch	03.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 16V (DERFNF, DERFNC, RERFNC)	136 ch	06.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 16V HPi (DERLZB)	140 ch	06.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 HDi (DERHYB)	90 ch	06.2001 > 08.2004
C5 (04-08) (RC_) - 1.6 HDi (RC8HZB)	109 ch	09.2004 > 06.2008
C5 (04-08) (RC_) - 1.8 16V	125 ch	09.2005 > 06.2008
C5 (04-08) Break (RE_) - 1.8 16V	125 ch	09.2005 > 06.2008
PEUGEOT		
308 (08-13) (4A_, 4C_) - 1.6 16V	120 ch	09.2007 >
	140 ch	09.2007 >
	150 ch	09.2007 >
	174 ch	03.2008 >
308 (08-13) (4A_, 4C_) - 1.6 BioFlex	109 ch	04.2008 >
308 (08-13) (4A_, 4C_) - 1.6 GTi	200 ch	07.2010 >
308 (08-13) (4A_, 4C_) - 1.6 HDi 90	90 ch	09.2007 >
308 (08-13) (4A_, 4C_) - 1.6 HDi 92	92 ch	11.2009 >
308 (08-13) (4A_, 4C_) - 1.6 HDi 109	109 ch	09.2007 >
308 (08-13) (4A_, 4C_) - 1.6 HDi 112	112 ch	12.2009 >
308 (09-13) CC - 1.6 16V	120 ch	06.2009 >
	140 ch	06.2009 >
	150 ch	06.2009 >
	156 ch	06.2009 >
308 (09-13) CC - 1.6 HDi	112 ch	06.2009 >
308 (09-13) CC - 1.6 THP	200 ch	10.2010 >
308 (08-13) SW - 1.4 16V	95 ch	09.2007 >
	98 ch	12.2009 >
308 (08-13) SW - 1.6 16V	120 ch	09.2007 >
	140 ch	09.2007 >
	150 ch	09.2007 >
	174 ch	03.2008 >
	156 ch	10.2009 >
308 (08-13) SW - 1.6 HDi	90 ch	09.2007 >
	92 ch	11.2009 >
	109 ch	09.2007 >
	112 ch	12.2009 >
5008 - 1.6 16V	120 ch	09.2009 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.