

## DONNEES TECHNIQUES

Compressed length [mm]	<b>650</b>
Uncompressed length [mm]	<b>670</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>59</b>
ABS ring type	<b>On hub</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
Number of splines (gearbox side)	<b>24</b>
(gearbox side) CV Joint Ø [mm]	<b>90</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>CITROËN</b>		
C5 (01-04) (DC_) - 2.0 16V (DCRFNC, DCRFNF)	136 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.0 16V HPi (DCRLZB)	140 ch	03.2001 > 08.2004
C5 (01-04) (DC_) - 2.0 HDi (DCRHYB)	90 ch	03.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 16V (DERFNF, DERFNC, RERFNC)	136 ch	06.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 16V HPi (DERLZB)	140 ch	06.2001 > 08.2004
C5 (01-04) Break (DE_) - 2.0 HDi (DERHYB)	90 ch	06.2001 > 08.2004
C5 (04-08) (RC_) - 1.6 HDi (RC8HZB)	109 ch	09.2004 > 06.2008

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.