

## DONNEES TECHNIQUES

Length [mm]	<b>707</b>
Number of splines (wheels side)	<b>21</b>
<b>for vehicles without ABS</b>	
(wheels side) shoulder Ø [mm]	<b>50</b>
(wheels side) CV Joint Ø [mm]	<b>86</b>
Number of splines (gearbox side)	<b>23</b>
(gearbox side) CV Joint Ø [mm]	<b>81</b>

## PHOTOS



## DOCUMENTS

- BT-100**    **Conseils de montage des cardans**
- BT-104**    **Soufflets et Triaxes FIAT**
- BT-105**    **Soufflets et Triaxes SEAT**
- BT-131**    **Refus des carcasses transmissions**

## APPLICATIONS

<b>RENAULT</b>		
CLIO (90-98) (_57_) - 1.4	80 ch	01.1991 > 09.1998
CLIO (90-98) (_57_) - 1.4 (B57J, C57J)	75 ch	01.1991 > 09.1998
CLIO (90-98) (_57_) - 1.7 (B574, C574)	92 ch	01.1991 > 12.1993
CLIO (90-98) (_57_) - 1.8 (B578, C578)	90 ch	08.1994 > 09.1998
CLIO (90-98) (_57_) - 1.9 D	54 ch	01.1997 > 02.1998
CLIO (90-98) (_57_) - 1.9 D (_576, _57L)	64 ch	01.1991 > 02.1998
CLIO (91-98) Société (S57_) - 1.9 D	65 ch	01.1991 > 02.1998

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.