

DONNEES TECHNIQUES

Length [mm]	468
	for vehicles without ABS
Ø mounting holes [mm]	8
Number of mounting bores	6
(wheels side) CV Joint Ø [mm]	100
(gearbox side) CV Joint Ø [mm]	100

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

BMW		
5 Series (88-96) (E34) - 518i	113 ch	08.1989 > 09.1995
	115 ch	08.1989 > 09.1995
5 Series (88-96) (E34) - 520i	129 ch	01.1988 > 08.1991
5 Series (88-96) (E34) - 520i 24V	150 ch	09.1989 > 09.1995
5 Series (88-96) (E34) - 524td	115 ch	03.1988 > 09.1995
5 Series (88-96) (E34) - 525i	170 ch	01.1988 > 08.1991
5 Series (88-96) (E34) - 525i 24V	192 ch	09.1989 > 09.1995
5 Series (88-96) (E34) - 525td	115 ch	04.1993 > 09.1995
5 Series (88-96) (E34) - 525tds	143 ch	09.1991 > 09.1995
5 Series (88-96) Break/Touring (E34) - 518g	115 ch	11.1995 > 06.1996
5 Series (88-96) Break/Touring (E34) - 518i	113 ch	03.1993 > 09.1994
	115 ch	09.1994 > 01.1997
5 Series (88-96) Break/Touring (E34) - 520i	150 ch	11.1991 > 01.1997
5 Series (88-96) Break/Touring (E34) - 525i	192 ch	11.1991 > 01.1997
5 Series (88-96) Break/Touring (E34) - 525td	115 ch	03.1993 > 01.1997
5 Series (88-96) Break/Touring (E34) - 525tds	143 ch	12.1991 > 01.1997