

DONNEES TECHNIQUES

Length [mm]	590
Number of splines (wheels side)	30
	for vehicles with ABS
(wheels side) shoulder Ø [mm]	65
Position the retaining clip	Gearbox side
ABS ring type	On hub
(wheels side) CV Joint Ø [mm]	98
Number of splines (gearbox side)	27
(gearbox side) CV Joint Ø [mm]	86
(gearbox side) shoulder Ø [mm]	30

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

BMW		
X5 (99-06) (E53) - 3.0d	184 ch	05.2001 >
	218 ch	12.2003 >
X5 (99-06) (E53) - 3.0i	222 ch	05.2000 >
	231 ch	05.2000 >
X5 (99-06) (E53) - 4.4i	286 ch	05.2000 >
	320 ch	12.2003 >
X5 (99-06) (E53) - 4.6is	347 ch	02.2002 >
X5 (99-06) (E53) - 4.8is	360 ch	04.2004 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.