

## DONNEES TECHNIQUES

Length [mm]	<b>640</b>
Number of splines (wheels side)	<b>28</b>
Number of Teeth, ABS ring	<b>51</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>102</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>98</b>
(gearbox side) rollers Ø [mm]	<b>37</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>RENAULT</b>		
MASTER (98-03) Bus (JD/ND) - 1.9 dCi 80	82 ch	11.2001 >
MASTER (98-03) Bus (JD/ND) - 1.9 dTI	80 ch	09.2000 >
MASTER (98-03) Camionnette (FD) - 1.9 dCi 80	82 ch	11.2001 >
MASTER (98-03) Camionnette (FD) - 1.9 dTI	80 ch	09.2000 >

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.