

DONNEES TECHNIQUES

Compressed length [mm]	685
Uncompressed length [mm]	720
Number of splines (wheels side)	28
Number of Teeth, ABS ring	51
for vehicles with ABS	
ABS Ring Ø [mm]	102
ABS ring type	R
(wheels side) CV Joint Ø [mm]	102
Number of splines (gearbox side)	39

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
MASTER (03-10) Bus (JD) - 3.0 dCi 140 (JD0T)	136 ch	10.2003 >
MASTER (03-10) Camionnette (HD, FD) - 3.0 dCi 140 (HD0S, FD0S, HD1S)	136 ch	10.2003 >
MASTER (03-10) plateau (ED, UD) - 3.0 dCi 140 (ED0S, UD0S)	136 ch	10.2003 >

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.