

DONNEES TECHNIQUES

Compressed length [mm]	1115
Number of splines (wheels side)	28
Number of Teeth, ABS ring	51
	for vehicles with ABS
ABS Ring Ø [mm]	102
(wheels side) shoulder Ø [mm]	66
ABS ring type	R
(wheels side) CV Joint Ø [mm]	98
Number of splines (gearbox side)	39
(gearbox side) CV Joint Ø [mm]	86

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
MASTER (03-10) Bus (JD) - 2.5 dCi	120 ch	08.2006 >
MASTER (03-10) Camionnette (HD, FD) - 2.5 dCi	101 ch	08.2006 >
	120 ch	08.2006 >
	146 ch	08.2006 >
MASTER (03-10) Camionnette (HD, FD) - 3.0 dCi 120	116 ch	06.2005 >
MASTER (03-10) Camionnette (HD, FD) - 3.0 dCi 160	156 ch	06.2005 >
MASTER (03-10) plateau (ED, UD) - 2.5 dCi	120 ch	08.2006 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.