

DONNEES TECHNIQUES

Length [mm]	1125
Number of splines (wheels side)	28
Number of Teeth, ABS ring	51
	for vehicles with ABS
ABS Ring Ø [mm]	102
(wheels side) shoulder Ø [mm]	68
ABS ring type	R
(wheels side) CV Joint Ø [mm]	98
Number of splines (gearbox side)	39
(gearbox side) CV Joint Ø [mm]	85

PHOTOS




DOCUMENTS

- | | |
|---------------|--|
| BT-100 | Conseils de montage des cardans |
| BT-104 | Soufflets et Triaxes FIAT |
| BT-105 | Soufflets et Triaxes SEAT |
| BT-131 | Refus des carcasses transmissions |

APPLICATIONS

OPEL		
MOVANO Combi (J9) - 2.5 D	80 ch	07.1998 > 09.2000
MOVANO Combi (J9) - 2.8 DTI	114 ch	07.1998 > 10.2001
MOVANO Fourgon (F9) - 2.5 D	80 ch	01.1999 > 09.2000
MOVANO Fourgon (F9) - 2.8 DTI	114 ch	01.1999 > 10.2001
MOVANO Kipper (H9) - 2.5 D	80 ch	01.1999 > 09.2000
MOVANO Kipper (H9) - 2.8 DTI	114 ch	01.1999 > 10.2001
MOVANO Plateau (U9, E9) - 2.5 D	80 ch	07.1998 > 09.2000
MOVANO Plateau (U9, E9) - 2.8 DTI	114 ch	07.1998 > 10.2001
RENAULT		
MASTER (98-03) Bus (JD/ND) - 2.5 D	80 ch	07.1998 > 01.2001
MASTER (98-03) Bus (JD/ND) - 2.8 dTI	114 ch	07.1998 > 10.2001
MASTER (98-03) Camionnette (FD) - 2.5 D	80 ch	07.1998 > 01.2001
MASTER (98-03) Camionnette (FD) - 2.8 dTI	114 ch	07.1998 > 10.2001
MASTER (98-03) plateau (ED/HD/UD) - 2.5 D	80 ch	07.1998 > 01.2001
MASTER (98-03) plateau (ED/HD/UD) - 2.8 dTI	114 ch	07.1998 > 10.2001

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.