

DONNEES TECHNIQUES

Compressed length [mm]	830
Number of splines (wheels side)	32
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	27
(gearbox side) CV Joint Ø [mm]	90

PHOTOS



DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

RENAULT


MASTER (80-98) Bus (T__) - 28-35 2.5 TD	98 ch	08.1989 > 07.1998
MASTER (80-98) Bus (T__) - 28-35 2.0	79 ch	10.1986 > 07.1998
	80 ch	01.1983 > 09.1986
MASTER (80-98) Bus (T__) - 28-35 2.1 D	60 ch	01.1983 > 07.1998
MASTER (80-98) Bus (T__) - 28-35 2.4 D	71 ch	01.1983 > 08.1989
MASTER (80-98) Bus (T__) - 28-35 2.5 D	75 ch	08.1989 > 07.1998
MASTER (80-98) Bus (T__) - 30 2.2	91 ch	01.1983 > 07.1998
MASTER (80-98) Bus (T__) - 35 2.5 TD	94 ch	08.1989 > 07.1998
MASTER (80-98) Camionnette (T__) - 28-35 2.5 D	75 ch	08.1989 > 07.1998
MASTER (80-98) Camionnette (T__) - 28-35 2.5 TD	98 ch	08.1989 > 07.1998
MASTER (80-98) Camionnette (T__) - 28-35 2.0	79 ch	10.1986 > 07.1998
	80 ch	01.1983 > 10.1986
MASTER (80-98) Camionnette (T__) - 28-35 2.1 D	60 ch	01.1983 > 07.1998
MASTER (80-98) Camionnette (T__) - 28-35 2.4 D	71 ch	01.1983 > 08.1989
MASTER (80-98) Camionnette (T__) - 30 2.2	91 ch	01.1983 > 07.1998
MASTER (80-98) Camionnette (T__) - 35 2.5 TD	94 ch	08.1989 > 07.1998
MASTER (80-98) plateau (P__) - 28-35 2.0	79 ch	10.1986 > 07.1998
	80 ch	01.1983 > 09.1986

RENAULT

MASTER (80-98) plateau (P__) - 28-35 2.5 D

71 ch

09.1980 > 07.1998

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.