

DONNEES TECHNIQUES

Length [mm]	800
Number of splines (wheels side)	23
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	23

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
LAGUNA (94-01) (B56_, 556_) - 2.0 16V (B56D, B56M)	139 ch	06.1995 > 12.1996
LAGUNA (94-01) (B56_, 556_) - 2.2 D (B56F, B562)	83 ch	11.1993 > 12.1996
LAGUNA (95-01) Nevada (K56_) - 2.0 16V (K56D, K56M)	139 ch	09.1995 > 12.1996
LAGUNA (95-01) Nevada (K56_) - 2.2 D (K56F, K562, S56F)	83 ch	09.1995 > 12.1996

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.