

## DONNEES TECHNIQUES

Length [mm]	<b>660</b>
Number of splines (wheels side)	<b>23</b>
Number of Teeth, ABS ring	<b>44</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>85</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
(gearbox side) rollers Ø [mm]	<b>30</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>RENAULT</b>		
LAGUNA (94-01) (B56_, 556_) - 2.0 16V (B56D, B56M)	139 ch	06.1995 > 12.1996
LAGUNA (94-01) (B56_, 556_) - 2.2 D (B56F, B562)	83 ch	11.1993 > 12.1996
LAGUNA (95-01) Nevada (K56_) - 2.0 16V (K56D, K56M)	139 ch	09.1995 > 12.1996
LAGUNA (95-01) Nevada (K56_) - 2.2 D (K56F, K562, S56F)	83 ch	09.1995 > 12.1996

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.