

DONNEES TECHNIQUES

Length [mm]	800
Number of splines (wheels side)	27
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	57
(wheels side) CV Joint Ø [mm]	94
Number of splines (gearbox side)	23

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
LAGUNA (01-07) (BG0/1_) - 1.6 16V	112 ch	02.2005 >
LAGUNA (01-07) (BG0/1_) - 1.6 16V (BG0A, BG0L)	107 ch	03.2001 >
LAGUNA (01-07) (BG0/1_) - 1.8 16V	117 ch	03.2001 >
LAGUNA (01-07) (BG0/1_) - 1.8 16V (BG06, BG0J, BG0M)	116 ch	03.2001 >
LAGUNA (01-07) (BG0/1_) - 1.8 16V (BG0B, BG0M)	120 ch	03.2001 >
LAGUNA (01-07) (BG0/1_) - 1.8 16V (BG0C, BG0V)	121 ch	03.2001 >
LAGUNA (01-07) (BG0/1_) - 1.9 dCi	92 ch	03.2004 >
LAGUNA (01-07) (BG0/1_) - 1.9 dCi (BG0E)	105 ch	06.2001 >
LAGUNA (01-07) (BG0/1_) - 1.9 dCi (BG0R)	100 ch	10.2001 >
LAGUNA (01-07) (BG0/1_) - 2.0 16V IDE (BG0N)	140 ch	04.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.6 16V	112 ch	02.2005 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.8 16V	121 ch	03.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.8 16V (KG0B, KG0M)	120 ch	03.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.9 dCi	92 ch	03.2004 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.9 dCi (KG0E)	105 ch	06.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.9 dCi (KG0R)	100 ch	10.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 2.0 16V (KG00, KG0K, KG0W)	135 ch	08.2002 >
LAGUNA (01-07) Grandtour (KG0/1_) - 2.0 16V IDE (KG0N, KG0P)	140 ch	04.2001 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.