

DONNEES TECHNIQUES

Length [mm]	970
Number of splines (wheels side)	27
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	57
(wheels side) CV Joint Ø [mm]	94
Number of splines (gearbox side)	39

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
LAGUNA (01-07) (BG0/1_) - 1.9 dCi	107 ch	03.2001 >
	110 ch	01.2005 >
LAGUNA (01-07) (BG0/1_) - 1.9 dCi (BG0G)	120 ch	03.2001 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.9 dCi	107 ch	03.2001 >
	110 ch	01.2005 >
LAGUNA (01-07) Grandtour (KG0/1_) - 1.9 dCi (KG0G)	120 ch	03.2001 >

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.