

## DONNEES TECHNIQUES

Compressed length [mm]	<b>675</b>
Uncompressed length [mm]	<b>700</b>
Number of splines (wheels side)	<b>23</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>49</b>
ABS ring type	<b>On hub</b>
(wheels side) CV Joint Ø [mm]	<b>81</b>
Number of splines (gearbox side)	<b>26</b>
(gearbox side) CV Joint Ø [mm]	<b>77</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>RENAULT</b>		
KANGOO (2008-) (KW0/1_) - 1.5 dCi 70	68 ch	02.2008 >
KANGOO (2008-) (KW0/1_) - 1.6	87 ch	02.2008 >
KANGOO (2008-) BE BOP (KW0/1_) - 1.6	106 ch	02.2009 >
KANGOO (2008-) Grand Kangoo (KW0/1_) - 1.5 dCi 75	75 ch	11.2012 >
KANGOO (2008-) Grand Kangoo (KW0/1_) - 1.5 dCi 90	90 ch	11.2012 >
KANGOO (2008-) Express (FW0/1_) - 1.5 dCi 70	68 ch	02.2008 >
KANGOO (2008-) Express (FW0/1_) - 1.5 dCi 75	75 ch	09.2010 >
KANGOO (2008-) Express (FW0/1_) - 1.6	87 ch	02.2008 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.4 16V	82 ch	10.2003 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.4 16V (BM0B, CM0B)	98 ch	11.2002 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.5 dCi	86 ch	05.2005 >
	101 ch	10.2003 >
	103 ch	01.2007 >
	106 ch	05.2005 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.5 dCi (BM0F, CM0F)	82 ch	11.2002 >

<b>RENAULT</b>		
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.6 16V	112 ch	01.2007 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.6 16V (BM0C, CM0C)	113 ch	11.2002 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.6 Flex-Fuel	105 ch	01.2007 >
MEGANE (02-08) 3 volumes (LM0/1_) - 1.4	98 ch	09.2003 >
MEGANE (02-08) 3 volumes (LM0/1_) - 1.5 dCi	82 ch	09.2003 >
	101 ch	02.2004 >
	103 ch	01.2007 >
MEGANE (02-08) 3 volumes (LM0/1_) - 1.6	113 ch	09.2003 >
MEGANE (02-08) 3 volumes (LM0/1_) - 1.6 16V	112 ch	01.2007 >
MEGANE (02-08) Break (KM0/1_) - 1.5 dCi	82 ch	09.2003 >
	86 ch	05.2005 >
	101 ch	02.2004 >
	103 ch	01.2007 >
	106 ch	05.2005 >
MEGANE (02-08) Break (KM0/1_) - 1.6	113 ch	09.2003 >
MEGANE (02-08) Break (KM0/1_) - 1.6 16V	112 ch	01.2007 >
MEGANE (02-08) Break (KM0/1_) - 1.6 16V Hi-Flex	105 ch	02.2008 >
MEGANE (02-08) CC (EM0/1_) - 1.5 dCi	103 ch	01.2007 >
MEGANE (02-08) CC (EM0/1_) - 1.6	113 ch	09.2003 >
MEGANE (02-08) CC (EM0/1_) - 1.6 16V	112 ch	01.2007 >
<b>SUZUKI</b>		
ALTO (94-02) (EF) - 1.0	58 ch	01.2000 >
<b>VOLVO</b>		
940 (90-94) (944) - 2.0 Turbo	155 ch	08.1990 > 12.1994

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.