

## DONNEES TECHNIQUES

Compressed length [mm]	<b>930</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>53</b>
ABS ring type	<b>On hub</b>
(wheels side) CV Joint Ø [mm]	<b>84</b>
Number of splines (gearbox side)	<b>39</b>
(gearbox side) CV Joint Ø [mm]	<b>81</b>
(gearbox side) shoulder Ø [mm]	<b>33</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

### RENAULT


GRAND SCÉNIC (04-10) (JM0/1_) - 1.9 dCi	110 ch	05.2005 >
	120 ch	04.2004 >
	131 ch	05.2005 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.9 dCi	131 ch	05.2005 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 1.9 dCi (BM0G, CM0G)	120 ch	11.2002 >
MEGANE (02-08) (BM0/1_, CM0/1_) - 2.0 16V (BM0U, CM0U)	135 ch	11.2002 >
MEGANE (02-08) 3 volumes (LM0/1_) - 1.9 dCi	120 ch	09.2003 >
	131 ch	05.2005 >
MEGANE (02-08) Break (KM0/1_) - 1.9 dCi	120 ch	09.2003 >
	131 ch	05.2005 >
MEGANE (02-08) CC (EM0/1_) - 1.9 dCi	120 ch	09.2003 >
MEGANE (02-08) CC (EM0/1_) - 2.0	135 ch	09.2003 >
SCÉNIC (03-09) (JM0/1_) - 1.9 dCi	110 ch	05.2005 >
	131 ch	05.2005 >
SCÉNIC (03-09) (JM0/1_) - 1.9 dCi (JM12)	120 ch	06.2003 >

**RENAULT**

SCÉNIC (03-09) (JM0/1\_) - 2.0 16V Turbo (JM0W)

163 ch

05.2004 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.