

DONNEES TECHNIQUES

Length [mm]	933
Number of splines (wheels side)	23
Number of Teeth, ABS ring	30
	for vehicles with ABS
ABS Ring Ø [mm]	87
ABS ring type	R
(wheels side) CV Joint Ø [mm]	98
Number of splines (gearbox side)	26
(gearbox side) CV Joint Ø [mm]	96

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions


APPLICATIONS

RENAULT

SAFRANE (96-00) (B54_) - 2.0 16V (B54L)

136 ch

07.1996 > 12.2000

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.