

## DONNEES TECHNIQUES

Length [mm]	<b>650</b>
Number of splines (wheels side)	<b>21</b>
	<b>for vehicles without ABS</b>
(wheels side) CV Joint Ø [mm]	<b>86</b>
(gearbox side) rollers Ø [mm]	<b>30</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>RENAULT</b>		
MEGANE (95-02) (BA0/1_) - 1.4 16V (BA0D, BA1H, BA0W, BA10)	95 ch	03.1999 >
MEGANE (95-02) (BA0/1_) - 1.4 e (BA0E, BA0V)	75 ch	01.1996 > 02.1999
MEGANE (95-02) (BA0/1_) - 1.4 Eco (BA0T)	71 ch	01.1996 > 03.1999
MEGANE (95-02) (BA0/1_) - 1.6 16V (BA11, BA04, BA0B, BA1J)	107 ch	03.1999 >
MEGANE (95-02) (BA0/1_) - 1.6 e (BA0F, BA0S)	90 ch	01.1996 > 03.1999
MEGANE (95-02) (BA0/1_) - 1.6 i (BA0L)	75 ch	01.1996 > 03.1999
MEGANE (95-02) (BA0/1_) - 1.8 16V (BA06, BA12, BA1A, BA1M, BA1R)	115 ch	01.2001 > 01.2002
MEGANE (95-02) (BA0/1_) - 1.9 D Eco (BA0U, SA0U, BA0A)	64 ch	01.1996 > 02.1999
MEGANE (95-02) (BA0/1_) - 1.9 dT (BA0K, SA0K, BA0Y, SA0Y)	90 ch	01.1996 >
MEGANE (95-02) (BA0/1_) - 2.0 i	109 ch	03.1999 >
MEGANE (95-02) (BA0/1_) - 2.0 i (BA0G)	114 ch	01.1996 > 12.1998
MEGANE (95-02) Break (KA0/1_) - 1.4 16V (KA0D, KA1H, KA0W, KA10)	95 ch	03.1999 >
MEGANE (95-02) Break (KA0/1_) - 1.4 e (KA0V)	75 ch	03.1999 >
MEGANE (95-02) Break (KA0/1_) - 1.6 16V (KA0B, KA04, KA11)	107 ch	03.1999 >
MEGANE (95-02) Break (KA0/1_) - 1.6 e (KA0F)	90 ch	03.1999 >
MEGANE (95-02) Break (KA0/1_) - 1.8 16V (KA0S, KA12, KA1A, KA1M, KA1R)	115 ch	01.2001 >
MEGANE (95-02) Break (KA0/1_) - 1.9 D (KA0J, KA0R)	64 ch	04.1999 >
MEGANE (95-02) Cabriolet (EA0/1_) - 1.4 16V (EA0D, EA1H, EA0W, EA10)	95 ch	03.1999 >
MEGANE (95-02) Cabriolet (EA0/1_) - 1.6 16V (EA0B, EA04, EA11)	107 ch	03.1999 >

<b>RENAULT</b>		
MEGANE (95-02) Cabriolet (EA0/1_) - 1.6 e (EA0F)	90 ch	10.1996 > 03.1999
MEGANE (95-02) Cabriolet (EA0/1_) - 2.0 (EA0G)	114 ch	04.1997 >
MEGANE (95-02) Cabriolet (EA0/1_) - 2.0 i (EA0G)	109 ch	03.1999 >
MEGANE (95-02) Classic (LA0/1_) - 1.4 (LA0E, LA0V)	75 ch	09.1996 > 02.1999
MEGANE (95-02) Classic (LA0/1_) - 1.4 16V (LA0D, LA1H, IA0W, LA10)	95 ch	03.1999 >
MEGANE (95-02) Classic (LA0/1_) - 1.6 16V (La04, LA11, LA0B, LA1C, LA1J)	107 ch	03.1999 >
MEGANE (95-02) Classic (LA0/1_) - 1.6 e (LA0F, LA0S)	90 ch	09.1996 > 03.1999
MEGANE (95-02) Classic (LA0/1_) - 1.6 i (LA0L)	75 ch	09.1996 > 03.1999
MEGANE (95-02) Classic (LA0/1_) - 1.8 16V (LA06, LA12, LA1A, LA1M, LA1R)	115 ch	01.2001 > 01.2002
MEGANE (95-02) Classic (LA0/1_) - 1.9 D (LA0A, LA0U)	64 ch	09.1996 > 02.1999
MEGANE (95-02) Classic (LA0/1_) - 1.9 dT (LA0K, LA0Y)	90 ch	09.1996 >
MEGANE (95-02) Classic (LA0/1_) - 2.0 i	109 ch	03.1999 >
MEGANE (95-02) Classic (LA0/1_) - 2.0 i (LA07, LA0G)	114 ch	09.1996 > 12.1998
MEGANE (95-03) Coupé (DA0/1_) - 1.4 16V (DA0D, DA1H, DA0W, DA10)	95 ch	03.1999 > 08.2003
MEGANE (95-03) Coupé (DA0/1_) - 1.6 16V (DA0B, DA04, DA11)	107 ch	03.1999 > 08.2003
MEGANE (95-03) Coupé (DA0/1_) - 1.6 e (DA0F)	90 ch	03.1996 > 03.1999
MEGANE (95-03) Coupé (DA0/1_) - 2.0 i	109 ch	03.1999 > 08.2003
MEGANE (95-03) Coupé (DA0/1_) - 2.0 i (DA0G)	114 ch	03.1996 > 08.2003
MEGANE (95-03) Scenic (JA0/1_) - 1.4 i (JA0E)	75 ch	01.1997 > 12.1998
MEGANE (95-03) Scenic (JA0/1_) - 1.6 e (JA0F)	90 ch	01.1997 > 12.1998
MEGANE (95-03) Scenic (JA0/1_) - 1.6 i (JA0L)	75 ch	01.1997 > 12.1998
SCÉNIC (99-03) (JA0/1_) - 1.4 16V (JA0D, JA1H, Ja0W, JA10)	95 ch	09.1999 > 08.2003

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.