

## DONNEES TECHNIQUES

Length [mm]	<b>742</b>
Number of splines (wheels side)	<b>21</b>
<b>for vehicles without ABS</b>	
(wheels side) CV Joint Ø [mm]	<b>86</b>
Number of splines (gearbox side)	<b>23</b>
(gearbox side) CV Joint Ø [mm]	<b>81</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>RENAULT</b>		
TWINGO (93-06) (C06_) - 1.2 (C063, C064)	55 ch	03.1993 > 10.1996
TWINGO (93-06) (C06_) - 1.2 (C066, C068)	58 ch	05.1996 > 11.1998
TWINGO (93-06) (C06_) - 1.2 (C067)	54 ch	05.1996 > 11.1998
TWINGO Société (S06_) - 1.2 (S063, S064)	55 ch	03.1993 > 05.1996
TWINGO Société (S06_) - 1.2 (S066, S068)	58 ch	05.1996 > 11.1998

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.